



Montagehinweis 2-1 Paralever SE-20-21043-01-015

Hinweis:

- Bei der Montage der Auspuffanlage darauf achten, dass das Motorrad sicher steht
- Motor und Auspuffanlage vor der Montage abkühlen lassen
- Anzugsmomente für Schrauben müssen aus der modellspezifischen Reparaturanleitung entnommen werden
- Die Auspuffanlage vor Erstinbetriebnahme gründlich reinigen
- Alle Schrauben der Auspuffverbindungen nach 50 Km nachziehen

Vorgehensweise:

1. Alle Auspuffschellen und Endschalldämpfer lösen
2. Den originalen Endschalldämpfer abbauen
3. Auspuffsammler abbauen

Hinweis: Einige Krümmeranlagen sind am Ende zum Auspuffsammler hin auf einen Durchmesser von 36mm verjüngt. Um das SE Y-Rohr montieren zu können, müssen die im originalen Sammler verbauten Alu Distanzhülsen (BMW Ersatzteilnummer: 18212331956 „Dichtung“) vorsichtig entnommen und für das Y-Rohr wiederverwendet werden!

4. Das zweiteilige Y-Rohr auf die Krümmer schieben und lose ausrichten
5. **Hinweis:** Die Rohrverbindungen zur leichteren Montage und gegen Festbrennen mit der beiliegenden Keramikpaste bestreichen und zusammenschieben!
6. Den Endschalldämpfer auf das dickere Ende des Y-Rohres aufschieben
7. Die Haltetasche des Endschalldämpfers wird mit der beigelegten Inbus-schraube M8x40 am Fußrastenträger **innen** verschrauben
8. Die Auspuffanlage ausrichten und alle Schraubverbindungen der Auspuffanlage von vorne nach hinten festziehen

Hinweis: Bei Bedarf kann es hilfreich sein die Krümmeranlage am Auslass und die Verschraubung des Interferenzrohres zu lösen, um die Auspuffanlage besser ausrichten zu können!

Viele Grüße vom Sport-Evolution Team!





Mounting instructions

2-1 Paralever

SE-20-21043-01-015

Hint:

- When installing the exhaust system, make sure that the motorcycle is securely in place
- Cool down engine and exhaust system before mounting
- Tightening torques for screws must be taken from the modelspecific repair instructions
- Thoroughly clean the exhaust system before using it for the first time
- Retighten all screws of the exhaust connections after 50 km

Procedure:

1. Loosen all exhaust clamps and silencer
2. Remove the original silencer
3. Remove the exhaust manifold

Note: Some manifolds are tapered to a diameter of 36mm at the end towards the exhaust manifold. In order to be able to mount the SE Y-pipe, the aluminium sleeves installed on the original manifold (BMW spare part number: 18212331956 "Seal") must be carefully removed and refitted to the Y-pipe!

4. Slide the two-piece Y-pipe onto the manifold and do not tighten up yet

Note: For easier assembly and to prevent burning, coat the pipe joints with the enclosed ceramic paste and push them together!

5. Push the silencer onto the larger end of the Y-pipe
6. The bracket of the rear silencer is screwed to the **inside** of the footrest panel with the enclosed Allen screw M8x40
7. Adjust the exhaust system and tighten all screw connections of the exhaust system from front to back, so everything is in line

Note: If necessary, it may be helpful to loosen the manifold at the outlet and the screw connection of the interference pipe in order to be able to align the exhaust system better!

Best regards from the Sport-Evolution Team!

